


LATERAL ADJUSTMENT

SCALE INDICATION ON 3127F AND 3152F



Cable drum											
FFHL54 HL max. 1370 mm	HL (mm)	1370	1002	634	266						
	Adjustment indication	1	2	3	4						
FFHL120 HL max. 3010mm	HL (mm)	3010	2520	2031	1541	1052	562	72			
	Adjustment indication	1	2	3	4	5	6	7			
FFHL164 HL max. 4100 mm	HL (mm)	4100	2673	3246	2819	2392	1965	1538	1110	683	256
	Adjustment indication	1	2	3	4	5	6	7	8	9	10